

Interconnect Components

Epsilon EP



CTVUE-303L,
-303M, -306A,
-306C, -308A,
or -310C

CTVUE HMI to Drive
CTVUE-EP-485-xxx

Drive RS485 to Drive RS485
DDC-RJ45-xxx

PC RS232 to Drive RS485
Serial Interface Cable, CT-COMMS

PC USB Port to Drive RS485
Serial Interface Cable
CT-USB-CABLE

Ethernet to Drive,
ETH-PATCH-xxx



Windows 98, NT 4.0, 2000
XP (32-bit) or Vista (32-bit)
Compatible Computer
(Customer Supplied)




Ethernet 8-port Switch,
ETH-S8

CT-MME-POWER-CD
Contains *PowerTools Pro*

Epsilon EP I/O Cable,
EIO26-xxx



STI-24IO



Braking Resistor,
SM-Heatsink DBR1



Drive Brake Relay
BRM-1

Motor Power Cable
XTMS-xxx*

40, 60, 80 mm
XV Motors

Motor Brake Cable
XTBMS-xxx*



Motor Feedback Cable
XUFTS-xxx*

130 mm XV Motors

Motor Power (+Brake) Cable
XCMS-xxx or XCMB-xxx*



Motor Feedback Cable
XUFC-xxx*

Motor Power Cable
CMDS-xxx or CMMS-xxx*

NT Motors

Motor Brake Cable
CBMS-xxx*



Motor Feedback Cable
UFCS-xxx*

Motor Power Cable
PSBAA-xxx, PBBAA-xxx**

FM Motors

Motor Feedback
SIBAA-xxx**



Drive Sync Out to
Drive Sync In Cable,
SNCDD-915-xxx

Drive Sync In to Drive Sync Out Cable,
SNCDD-915-xxx

Drive Sync Out Cable,
SNCFLA-xxx

Drive Sync In Cable,
SNCFLI-xxx

Drive Sync Out to
FM-3/4 Module In Cable,
SNCMD-815-xxx

Drive Sync In from
FM-3/4 Module Out Cable,
SNCMD-89-xxx




Drive Sync Out
Breakout Board,
STI-SNCOA



Master
Synchronization
Encoder SCSLD



Motor Feedback Breakout Board,
STI-ENC



Drive Sync In Breakout Board,
STI-SNCI

Cable Notes

- * Flex duty versions available
- ** Flex duty cable